

INSTRUCTION MANUAL

thanks for your choice on our products. It is very easy to use our product, please read the manual just before using it:

g	oz	ct	ozt	dwt	gn
50g/0.1g	1.76oz/0.01oz	2500x/0.5ct	16.1ozt/0.01ozt	322.0dwt/0.1dwt	7716/1gn
200g/0.01g	10.56oz/0.001oz	15000x/0.05ct	9.66ozt/0.001ozt	193.2dwt/0.01dwt	4629.6/0.1gn
200g/0.01g	7.04oz/0.001oz	10000x/0.05ct	6.44ozt/0.001ozt	128.8dwt/0.01dwt	3086.4/0.1gn
150g/0.01g	5.28oz/0.001oz	7500x/0.05ct	4.83ozt/0.001ozt	96.6dwt/0.01dwt	2314.8/0.1gn
100g/0.01g	3.52oz/0.001oz	5000x/0.05ct	3.22ozt/0.001ozt	64.4dwt/0.01dwt	1543.2/0.1gn
100g/0.1g	3.52oz/0.01oz	5000x/0.5ct	3.22ozt/0.01ozt	64.4dwt/0.1dwt	1543.2/1gn

Maximum metage: 1 minutes
 Automatically turning off: 10°C -30°C
 Operation temperature: 5 digit display
 LCD display: blue (other options)
 Backg light: 128x78x19mm
 Dimension: 2X"AAA" batteries
 Power: 12kg
 Weight: 69x64mm
 Super stainless tray:

Tare function
 Automatically & low-energy-consuming alarming system
 Option units: g/oz/ozt/dwt/ct/gn

Instruction:

1. Press the "ON" key, and wait for 5 seconds for 0.0.
2. Put the article on to the tray, when "S" appears, the display means the weight of the article.
3. Change the measuring unit by using the MODE key.
4. Press the TARE key to reset the 0 calibration.
5. OFF means shut down.
6. calibration function:
 Press "on" till it shows "8888" and "0.0". Press "on" again and hold it for 3 seconds till it displays "0". Then release the button. It displays the verifying value like 500.0 or 100.00 etc. (pres "TARE" Key it will change the weight value). When "g" is flickering, press the weight onto the pan. The weight value should be the capacity value of the scale. 5 seconds later, "g" stops flickering. The calibration is over

Notice:
 Remove the protection cover of the tray gently; the SCALE should be kept in a stable and windless condition.
 Never put on the tray the weight over the rated one, or the sensing part will be damaged; when applying the article, please conduct it in a gentle way.
 Do not making the phone call in a range of 50cm when using our product., or it will affect the result.
 When there is an S appears in the left & up corner, the display means the weight of the article.
 The there is the symbol of the battery appears in the display, it means you need to change battery.
 Please use our product in a condition of 10°C -30°C; a difference in temperature may cause error. If the is a noticeable difference, please use a weight to calibrate it. When doing this, a 30 minutes' using time must be guaranteed in a same surrounding.
 When overload, an "FULL" will appear.
 Please take good care of the scale

March-2009 Change Version